

## REMOTE: ALL LIGHTS TURN ON & STAY ON

1. Reset System by remove AC cord from Wall AC outlet for 1 minute. Plug AC cord back. If all Lights (LED) still stay on. Go to step 2
2. Move Remote Control to a good unit to find if all LED turn off as normal
3. If LED still stay on. Call Customer care at 1800 559-3630 request for a replacement.

**CAUTION:** Physical damage to the remote such as drop in water or broken housing is not cover under warranty.

